

LIEBERSEW™



NEW **LIEBERSEW™ 1377 MULTISTITCH BUTTON SEWER**

This new **BUTTON SEWER** has a new function which knots the button thread three times and prevents it from fraying.

Another new function is a lever which allows the change from 2 Hole to 4 Hole parallel and 4 Hole cross stitch quickly. A Special Liebersew advantage!!

Available electric or hand operated with stands.



Optional Tilt Bins For Button Storage Shown



LEVER FOR CHANGING STITCH TYPE



**B&G
LIEBERMAN**

2420 Distribution St. • Charlotte, NC 28203



FAX 1-800-248-2696

1-800-438-0347

www.bglieberman.com